



1 L | TB40-404-001

## **Gebrauchsanleitung**

Schön, dass du dich für eine **TRINKBASIS** Glasteekanne entschieden hast. Damit du möglichst lange Freude daran hast und immer gut trinkst, solltest du ein paar Hinweise beachten.

- Vor dem ersten Gebrauch die Teekanne einmal mit warmem Wasser ausspülen.
- Nach jeder Verwendung empfehlen wir eine gründliche Reinigung, um Ablagerungen und Teegeruch zu entfernen - auch in der Spülmaschine möglich.
- Keine scharfkantigen Gegenstände, Scheuer- oder Lösungsmittel sowie Bleichmittel zum Reinigen verwenden.
- Vermeide extreme Temperaturunterschiede, um ein Zerbrechen der Teekanne zu verhindern.
- Achtung, Verbrennungsgefahr! Das Sieb kann heiß werden und es kann heißer Wasserdampf entweichen.

Wir wünschen dir viel Spaß mit deiner **TRINKBASIS** Glasteekanne!



1 L | TB40-404-001



## Instructions for use

Thank you for choosing a TRINKBASIS glass tea pot. To ensure that you enjoy it for as long as possible, you should follow a few tips.

- Rinse the teapot with warm water before using it for the first time.
- After each use, we recommend thorough cleaning to remove any residue and tea odors. The tea pot and its parts are dishwasher-safe.
- Do not use sharp objects, abrasive cleaners, solvents, or bleach for cleaning.
- Avoid extreme temperature changes to prevent the teapot from breaking.
- Caution: Risk of burns! The strainer may become hot, and hot steam can escape.

We wish you lots of fun with your TRINKBASIS glass tea pot!